

MOUNTING INSTRUCTIONS

EWO® HWO heatingwater optimizer



APPLICATION

Black, muddy heating water results from unnatural conditions in the heating circuit, which can lead to technical problems.

A 1mm thick covering can increase energy consumption by up to 10%. Maintenance requirements and costs increase with poorly functioning heaters.

Thanks to the EWO® HWO – heatingwater-optimizer, the heating water remains in a stable equilibrium. The HWO can be used in systems with a system content of up to 500L.

FUNCTIONALITY

EWO® HWO works with the **3 mechanisms of the EWO®-method:**

- + turbulence
- + information transfer
- + magnetism


PRE-CONDITIONS FOR INSTALLATION

Local installation regulations, general guidelines and technical data must be noted.

The installation location must be frost-proof and ensure protection against chemicals, dyes, solvents, vapors and environmental influences.

MOUNTING INSTRUCTIONS

- Mounting in flow or return
- EWO® HWO has a **given** flow direction
- keep at least 50cm distance (linear distance) to electrical equipment, e.g. pumps (distance to electrical and electromagnetic fields)
- do not put live cables on or around water pipes



examples

Please note flow direction

TECHNICAL DATA

EWO® HWO		Technical Data		
Dimension	inch	1/2"	3/4"	1"
Nominal width	DN	15	20	25
Max. water pressure	bar	4		
Operating temperature	°C	1 – 70		
Flow rate Δ 0,1bar	m³/h	1	2,2	3,8
Flow rate Δ 0,2bar	m³/h	1,4	3,1	5,5
Total length	mm	58	70	88
Diameter	mm	25	30	39
Weight	kg	0,2	0,4	0,5
Boiler output	kW	15	20	25
Heating water volume, approx.	m³	0,2	0,3	0,5
Calming section	cm	10	15	20

OPERATION & MAINTENANCE

EWO® HWO is maintenance free

SCOPE OF DELIVERY

1 EWO® HWO heatingwater optimizer
1 mounting instructions

WARRANTY

The latest version of the national statutory warranty provisions apply.

Contact:

Name: EWO Wassertechnik GmbH
Street: Anzing 48
ZIP-Code: 4113
City: St. Martin/Mühlkreis
State: Austria
Tel: +43 7232 2754-0
E-Mail: office@ewo-wasser.at

The copyright of this manual remains with the manufacturer. No part of this manual may be reproduced, processed, or distributed using electronic systems in any form without the written permission of EWO Wassertechnik GmbH. The information corresponds to the knowledge available at the time of preparation. Printing errors, mistakes and changes are reserved. Illustrations are not to scale. All information is based on the characteristics of the Austrian market.
Editions: January 2021

